For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- **Brainshark Video Modules**

## Security

Manufacturer	Model	Auto Arming	Zone Bypassing	Zone Name detection	Multiple partitions	Min Core	Support thru	Notes
	<u>128FBP</u> <u>250FBP</u>					5.1	Current	1 access code, no relay support, No Panic Button
Ademco Honeywell	128BP 250BP FA1660C	•				4.0	Current	firmware v3 Only, NOTE: Firmware v4 (BPE) is not supported
	128BPT 250BPT				•	5.9	Current	no relay support, No Panic Button
Bosch Radionics	<u>D7000</u> <u>D9000</u>	•	•	•	•	4.0	Current	Firmware 6.80-7.07
	Concord	•	•	•	•	4.0	Current	Superbus must NOT end in -03
GE	NX4/6/8	•	•		•	5.1	Current	Cannot use pin codes ending in 0. MUST use NX-584 to interface RS232
	NX8E	•	•		•	4.0	Current	Cannot use pin codes ending in 0. MUST use P0003 to connect RS232.
Napco	<u>P9600</u>	•	•*		•	4.0	Current	Can be armed in 1 mode ONLY. Bypass Status does not reflect if done via Napco Keypad. serial brick not supported
Марсо	<u>X255</u>	•	•*		•	4.0	Current	Can be armed in 1 mode ONLY. Bypass Status does not reflect if done via Napco Keypad. serial brick not supported
HAI	Omni LT Pro II	•	•	•	•	5.1	Current	Panel MUST be grounded properly
Elk	M1 Gold M1 EZ8	•		•	•	4.0	Current	Firmware 4.3.8 main, 3.1.13 Boot, ELKRP 1.6.2. Tstats/Lighting not Supported
	<u>Maxsys</u>	•	•		•	5.1	Current	Can NOT arm in Stay mode
DSC	<u>Power</u> 5401	•			•	4.0	Current	Thermostats not supported
	Power IT-100	•			•	6.4	Current	Thermostats not supported
Texecom	Premier Elite	•	•	•	•	6.4	Current	640 Series Panel NOT Supported
Paradox	EVO 48/96/192/ 848 NE96	•		•	•	6.4	Current	



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

### **Door Locks**

Manufacturer	Model	Wireless type	Deadbolt	Lever	Min Core	Supported thru	Notes
Kwickset	<u>99100-0xx</u>	Zwave	•	•	5.8	Current	
Baldwin	8252.112.AC3 8252.112.AC3X 8285.150.AC3 8285.150.AC3X	Zwave	•	•	5.8	Current	Requires Leviton: VRCOP +3 Zwave bridge, VRUSB-1US USB
Yale	ARYD210, ARYD220, YRD220-ZW	Zwave	•	•	5.8	Current	programming stick, <u>Vizia RF+ installer</u> <u>tool software</u>
Schlage	BE369/FE599	Zwave			5.8	Current	



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- **Brainshark Video Modules**

### Climate

Manufacturer	Model	Connection Type	Remote sensor	Decimal Display	Min Core	Supported Thru	Notes
Aprilaire	<u>8870</u>	RS485	•		4.0	Current	
Aprilaire	<u>8800</u>	RS485	•		5.4	Current	Be sure to use REV 2 8800's
Carrier/Bryant	<u>Infinity</u> <u>Evolution</u>	Wired	•		4.0	Current	Must use serial brick to connect to S.A.M. if over 10 feet from HC.
Oamen/Bryant	<u>CZII</u>	Wired	•		5.1	Current	Requires 485 to 232 adaptor <i>and</i> 485 Isolator
HAI	Omnistat2	RS232	•*		5.1	Current	A remote sensor can only be used to replace the internal sensor
	<u>Omnistat</u>	RS232			4.0	Current	Use com port 1 or 2 only
Honeywell	<u>YTH8320ZW100</u> <u>7/U</u>	Zwave		•	5.8	Current	Requires Zwave network – See Door lock notes
KNX	<u>Various</u>	Wired		•	5.4	Current	Use Tapco gateway
Lutron	LR-HVAC-1 RA2 LR-HWLV- HVAC RA2	RF**	•		5.4	Current	Requires a Main Repeater, not stand alone
	LR-HVAC-1 QS LR-HWLV- HVAC QS	RF**	•		5.4	Current	Requires a QS Processor, not stand alone
	TR/TS40 TR/TS16 TR/TS60	RS485 RS232	•*		4.0	Current	A remote sensor can only be used to replace the internal sensor
RCS	<u>TZ45R</u>	Zwave	•*		5.8	Current	Requires Zwave network – See Door lock notes A remote sensor can only be used to replace the internal sensor.
Tekmar	Net 4	RS232	•*		4.0	Current	A remote sensor can only be used to replace the internal sensor.  Requires a NULL
Trane	TZEMT400BB3 2MAA	Zwave	•*		5.8	Current	Requires Zwave network – See Door lock notes A remote sensor can only be used to replace the internal sensor.

For details on what is supported and connectivity you must consult each specific integration note.

#### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

# Climate (continued)

Manufacturer	Model	Connection Type	Remote sensor	Decimal Display	Min Core	Supported Thru	Notes
2GIG	<u>CT30</u>	Zwave		•	5.8	Current	Requires Zwave network – See Door lock notes Auto mode not supported
Life Sense	<u>LT1002</u>	RS485		•	6.1	Current	Auto mode not supported
Vantage	InFusion	Wired Bus			6.1	Current	Circulate mode and History usage is NOT supported to due protocol limitations.
Heatmiser	<u>Heatmiser</u> <u>Tstats</u>	RS485 Wi-Fi			6.3	Current	
Cool Master	<u>Various</u>	RS232			6.4	Current	



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

## Lighting

Manufacturer	Model	Connection	Wireless Type	Min Core	Supported Thru	Notes
Centralite	<u>Jetstream</u>	Wireless	Zigbee	4.0	Current	
Centrainte	<u>Elegance</u>	Hardwired	N/A	4.1	Current	
KNX	<u>Various</u>	N/A	N/A	5.4	Current	Tapco gateway
Leviton	<u>ViziaRF</u>	Wireless	Zwave	4.0	Current	Uses the RZCOP NOT the VRCOP
	<u>Illuminations</u>	Hardwired Hybrid	Hybrid RF	4.0	Current	
Luturu	<u>Interactive</u>	Hardwired Hybrid	Hybrid RF	4.0	Current	
Lutron	<u>QS</u>	Hardwired Hybrid	Hybrid RF	5.4	Current	Must use Ethernet for auto detect
	Radio Ra	Wireless	RF	4.0	Current	
	Radio Ra 2	Wireless	RF	5.4	Current	Must use Ethernet for auto detect
ELAN Pulseworx	<u>PCS</u>	Hardwired	UPB	4.0	Current	Follow the <u>7 Rules of Reliability</u> Program using <u>Upstart</u> software
	<u>Q-link</u>	Hardwired	N/A	4.0	Current	
Vantage	InFusion	Hardwired Hybrid	N/A RF	6.1	Current	
ESI	<u>R2D7</u>	Hardwired	N/A	4.0	Current	
Somfy	<u>RTS</u>	Wireless	RF	4.0	Current	
	<u>URTSII</u>	Wireless	RF	4.0	Current	
Clipsal	<u>C-Bus</u>	Hardwired	N/A	6.3	Current	
Rako	Rako Bridge	Hardwired Wireless	N/A RF	6.3	Current	



For details on what is supported and connectivity you must consult each specific integration note.

#### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- **Brainshark Video Modules**

## Pool/Spa

Manufacturer	Model	Scheduling	Colored Lighting	Chlorinator	Min Core	Supported Thru	Notes
Jandy	<u>Aqualink</u>				4.0	Current	Jandy Serial Adapter 7620 is  REQUIRED  Adapter should located within 20 feet of Controller
Pentair	Easy touch Intelli touch	•	•	•	4.0	Current	

## Irrigation

Manufacturer	Model	Rain Sensor Supported	Min Core	Supported Thru	Notes
Hunter	SRC/SRC + Pro-C/ICC X-core ACC	•	4.0	Current	Irrigation Brick: HWEB-101  REQUIRED

## UPS/Surge

Manufacturer	Model	UPS	Surge	controllable outlets	Min Core	Supported Thru	Notes
APC	<u>HS-500</u>	•		2	4.0	6.1	
Panamax	MB100 MB1500	•	•	4	5.8	Current	
Panamax	M4315 M4320		•	8	5.8	Current	
Furman	<u>F1000/F1500</u>	•	•	4	5.8	Current	



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

### Recelvers

Manufacturer	Models	Min Core	Supported Thru	Notes
	3808/XX10 CI	4.0	Current	
	<u>2311/3311/4311</u>	5.2	Current	
Denon	<u>1912/2112/2312/3312</u>	5.4	Current	
	1613/1713/1913/2113/2313/3313	5.8	Current	
	<u>4520CI</u>	6.3	Current	
	<u>A800/1000/2000/3000</u>	5.2	Current	
	<u>A710/810/1010/2010/3010</u>	5.4	Current	
Yamaha	<u>A3020/2020/1020/820/720</u>	6.3	Current	
	RX-V1600/V2600, RX-Z9	4.0	Current	
	RX-V3900/V2065	4.0	Current	
	<u>DTR-4.9/5.9/6.9/7.9/8.9/9.9</u>		Current	Check the corresponding
	<u>DTR-4.6/5.4/5.6/6.6/7.4/7.6</u>		Current	integration note for
Integra	20.3/30.3/40.3/50.3/70.3/80.3 40.1/50.1/70.1/80.1 70.4/50.4/40.4		Current	
			Current	features and limitations on a particular
			Current	
	<u>TX-NR906/TX-SR876/PR-</u> <u>SC886/TX-SR806/TXSR706</u>	4.0	Current	make/model as there are
Onkyo	TX-NR1007/TX-NR3007/TX- NR5007	5.0	Current	variances among receiver models
	TX-NR515/616/717/818/1010/ 3010/5010	6.3	Current	receiver models
	SR5500/5600/7500/8001/8500/960 0/ SR5004/SR6004/SR7002/8002	5.0	Current	
	SR6006/SR5006	5.4	Current	
Marantz	SR6005/AV7005/SR7005	5.2	Current	
	<u>ST7001</u>	4.0	Current	
	SR5007/6007/7007, AV7701/8801, NR1602/1603	6.3	Current	
Pioneer	<u>VSX-60,</u> SC-61/SC-63/SC-65/SC-67/SC-68	5.8	Current	



For details on what is supported and connectivity you must consult each specific integration note.

#### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

## Multi Zone Distribution

Manufacturer	Models	Max Sources	Max Zones per chassis	Max Chassis	Min Core	Supported Thru	Notes	
ADA	<u>Suite 16</u>	16	16	6(96)	4.0	Current	REQUIRES ISO-CAT II or	
	8200	8	8	2(16)	4.0	Current	ISO-232	
B&K	<u>CT310, CT600,</u> <u>CT610</u>	9	6	1	4.0	6.1		
Matrix	<u>Series 4, 6, 8</u>	8	4,6,8	2 24/32	4.0	6.1		
Nexus	<u>C-6, C-6E</u>	5	6,12	1	4.0	6.1		
	<u>Concerto</u>	6	8	1	4.0	Current*	0 "11	
Nuvo	Grand Concerto	6	8	2 (16)	4.0	Current*	6.x will have support for the controller ONLY, no keypad	
11470	<u>Essentia</u>	6	6	1	4.0	Current*	devices	
	Essentia E6G	6	6	2 (12)	4.0	Current*		
Niles	GXR-2	6	6	2 (12)	5.4	Current		
Russound	<u>CAV6.6</u> <u>CAM6.6</u>	6	6	1	4.0	6.1*	6.x Zone controller ONLY, no	
	<u>Sphere</u>	12	8	1	5.1	6.1	keypad or RNET devices	
Speakercraft	MZC-64/66/88	6	4,6,8	4 24-32	4.0	Current		
Vaux Lattis	<u>LE-400, LE-800</u>	8	8	1	4.0	6.1		
Video Storm	CMX44, CMX84, CMX86, CMX88	4,8	4,8	1	4.0	6.1		
	<u>M86</u>	6	8	4(24)	5.1	Current	Via-net control only	
	<u>S86A S86P</u>	6	8	4(24)	4.0	Current	Requires S12XK to link chassis	
Elan	<u>S128P</u>	12	32	4(32)	4.0	Current	Requires S12XK to link chassis	
	<u>S1616A</u>	16*	16*	16(64)	5.4	Current	*Sources and outputs can be configured as mono or stereo Via-net control only	



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

### Video Switchers

Manufacturer	Models	Max Sources	Max Zones	Min Core	Supported Thru	Notes
Atlona	AT-PRO Series, AT-H2H Series	16	16	5.8	Current	HD44M Min Core 6.1 HD66M Min Core 6.4
Snap Av Binary	B-100 4x4,8x8, B-300 4x4,8x8	8	8	5.8	Current	
Elan	<u>V883, V885</u>	8	32 (4 Chassis)	5.1	Current	Component
Lian	<u>V8</u>	8	32 (4 Chassis)	5.1	Current	Composite
Xantech	<u>HD44C, HD44CC5</u>	4	4	5.8	Current	Component
Adillecti	<u>HD88C, HD88CC5</u>	8	8	5.8	Current	Component
Video Storm	<u>CRM62, CRM84</u>	8	4/8	4.0	6.1	Component
Gefen	EXT-HDFST-848CPN, GTB-HDFST-848, GEFHDFST-848- 4ELR, GEF-HDFST- 848-8ELR,GTB- HDFST-444, GEF- HDFST-444	4/8	4/8	6.3	Current	Tested Firmware 3.1
WyreStorm	MX-0808-PP, MX- 0606-PP, MX-0404- PP, MX-0804-PP, MX-1616-310, MX- 0816-310, MX-0808- 310	16	16	6.4	Current	
Just Add Power	SG300-10/10P/ 10MP/20/28/28P/52 SG500- 28/28P/52/52P SG500X- 24/24P/48/48P	Many	Many	6.4	Current	Cisco SG300 or SG500 Switches ONLY



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

### Sources

Manufacturer	Model	Min Core	Supported Thru	Notes
	Logitech Media Server	6.0	Current	LMS must run on a local PC 24/7
Logitech	Squeezebox touch OLD <u>Driver</u>	4.0	Current	Pandora/Rhapsody Only
	<u>classic</u>	4.0	Current	
Fusion Research	<u>OMS 1,2,3</u>	6.0	Current	
ADA	Tune Suite	4.0	Current	
Integra	<u>TUN 3.7</u>	4.0	Current	
Nexus	<u>T-2</u>	4.0	6.1	
Nuvo	<u>T2</u>	4.0	6.1	
	<u>T2SIR</u>	4.0	6.1	
Russound	ST2 AM/FM/XM/Sirius	4.0	6.1	
Sonance iPort	<u>FS-4, FS-5, FS-22, IW-4, IW-5, IW-22, FS-23</u>	5.1*	Current	FS-23 Min Core 5.8
Sony	BDP-CX7000ES	5.1	Current	
Sirius	SCH1P1, SCH2P	4.0	Current	
	<u>DTNR</u>	4.0	Current	
Elan	<u>DT11, DT22</u>	5.0	Current	MDO MANA MAA ONII V
	HC internal player	5.2	Current	MP3, WAV, M4A ONLY MAX 65,000 tracks
Parasound	Ztuner v.2	4.0	6.1	
Kaleidescape	M300, M500, Cinema One	6.4	Current	One way – OSD control ONLY
Cu ou AV	WPS-300-DVR 9/16 CH	6.4	Current	One way – OSD control ONLY
Snap AV	WPS-300-NVR	6.4	Current	One way – OSD control ONLY



For details on what is supported and connectivity you must consult each specific integration note.

### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

## VIdeo Cameras/Encoders

Manufacturer	Model	Min Core	Supported Thru	Notes
	Standard Models (5.2 and earlier)	4.0	Current	Soo Integration Notes for specific
Panasonic	Standard Models	6.1	Current	See Integration Notes for specific camera models
	<u>iPro Models</u>	6.1	Current	camera modele
Aviosys	9100B (HWAVO100)	4.0	Current	
	<u>P5512</u>	6.1	Current	
	<u>P3301</u>	6.1	Current	
Axis	<u>214PTZ</u>	4.0	Current	
ANIS	<u>216FD</u>	4.0	Current	
	<u>7014/7001</u>	6.1	Current	
	<u>240/241Q</u>	4.0	Current	
	7xxx/8xxx	5.8	Current	See Integration Notes for specific
Vivotek	<u>VS8x01</u>	5.8	Current	models
	<u>VS2403</u>	5.1	Current	
DVR	See Integration Note	5.0	Current	50 GB MAX Storage
Snap AV	<u>WirePath</u>	6.4	Current	See Integration Notes for specific camera models
	WPS-300-DVR 9/16 CH	6.4	Current	Live feeds ONLY





For details on what is supported and connectivity you must consult each specific integration note.

#### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

## General Input/output Devices

Manufacturer	Model	Min Core	Supported Thru	Notes
HC4,6,8,12	Extender Mode	6.0	Current	Via-net and audio does not extend
Moxa Nport	<u>5410</u> , <u>5610</u>	4.0	Current	Uses their own db9 adaptor
KNX	Various Input/output	5.4	Current	
Global Cache	<u>GC-100-6/12/18</u>	4.0	Current	
	<u>iTach, iTach Flex</u>	6.4	Current	Sense Inputs NOT Supported
Just Add Power	<u>2G, 2G+</u>	6.4	Current	Utilizing Cisco SG Switches ONLY

## g! Interface Notes

Model	Min Core	Supported Thru	Notes
HR2 Integration Note	5.2	Current	Use AES Wi-Fi security
TS2 Integration note	5.1	Current	Uses Via-Net wiring
iOS Integration Note gMobile 5	4.0	5.9	
iOS Integration Note gMobile 6	6.0	Current	
Android Integration Note	6.0	Current	
gMod Integration Note	5.1	Current	GPASL Required

## Tech Notes

Important note when using ISP provided Routers – Verizon Fios, Uverse exc.

Changing the HC controller's name

How to add Music or Pictures to the internal Drive of a HC8/12

Email messaging, Alerts, and Notifications

Connections Reference Guide

Using Generic Zone Controllers

Check out our Forum

**Configurator Training Manual** 

Advanced Configurator and Reference Manual

**Unsupported Driver Guide** 

**User Settings Guide** 

User Door Lock Guide



For details on what is supported and connectivity you must consult each specific integration note.

#### Refer to the integration notes for the Complete Integration Guide

Current as of Core Module 6.4

- Associated Release Notes
- Brainshark Video Modules

GPAS	LLi	censing Sumn	nary
Subsystem	Virtual	Base (included)	Pro

Subsystem	Virtual	Base (included)	Pro (GPASL REQUIRED)	
Security	•	1 Partition, 8 Zones 1 Door Lock	8 Partitions, 256 zones 32 Door Locks	
Climate	•	2 Thermostats	32 Thermostats	
Lighting	•	16 Loads or Scenes256 Loads or Scenes32 g! Lighting Keypads64 g! Lighting Keypads32 g! Customizable Scenes32 g! Customizable Scenes		
Media	•	<ul> <li>64 ELAN A/V Zones</li> <li>1 3<sup>rd</sup> Party Supported AVR</li> <li>8 Sunfire AVR'S</li> <li>4 Generic Single Zone Controllers</li> </ul>	<ul> <li>64 A/V Zones (Any Brand)</li> <li>8 3<sup>rd</sup> Party Supported AVR</li> <li>8 Sunfire AVR'S</li> <li>32 Generic Single Zone Controllers</li> </ul>	
Video		2 video streams	16 video streams	
Irrigation	•	N/A	16 groups, 256 Zones	
Pool/Spa	•	N/A	1 Pool Controller	
DVR		N/A	16 cams, 50 gig max storage	
Messaging		Voicemail Box     Internal Voicemail (Not Telephone)     Email Notifications	8 Voicemail Boxes Telephone Voicemail – gMod Required Telephone Home Control – gMod Required Text to Speech	

## GVSL Licensing Summary

Core Module	Included	Additional	Unlimited (32) 3 <sup>rd</sup> Party viewers
Up to 5.9	1	Added individually	N/A
6.0 or Higher	1	Up to 3 additional	4 total licenses

#### **NOTE:**

Please refer to the Integration Note for the specific sub-system to understand any limitations associated with the particular device.

